

Addendum #2 Sink Concrete Step and ADA Sidewalk

Question regarding the subbase: If the concrete sidewalks and slabs are setting directly on top of soil, will 4" need to be removed and replaced with 4" aggregate base?

Answer: Remove 4" of subgrade to add 4" of new ABC. Subgrade to be compacted before installation of a ABC stone base 4" thick.

Below is a utility drawing showing the utilities leading into the building. BRCC wants to emphasize that the Contractor will be responsible to call 811 Location Services and locate underground utilities before digging or excavation takes place. No work is to proceed until location services are complete.

